The future of Sample Preparation





Affordable, rapid, reproducible and convenient

Not shaken, not stirred, ultra fast Sample Preparation using **SPEx** technologies.

SPEX TECHNOLOGIES



Forced Jet Mixing (FJM)

High turnover of fluid volume for rapid homogeneity and dissolution



High Frequency Pulverizing (HFP)

Focused pulverization of whole solids into powders, enhancing rapid extraction



Say goodbye to glassware, cleaning, cleaning validation and carryover.



25-100mL 100-500mL



Step 1: Clip Extraction Pouch to cassette



Step 2: Add solid dosage form and solvent to Extraction Pouch



Step 3: Load cassette onto SPEx unit



Step 4: Dry High Frequency Pulverize, then Force Jet Mix or Force Jet Mix and High Frequency Pulverize simultaneous for quickly extracting a wide range of sample types



Step 5: Remove extracted sample from SPEx Extraction Pouch



Step 6: No cleaning, no cleaning validation, no carryover — simply dispose of the Extraction Pouch

A revolution coming soon

Register your interest for more information, product specification and availability at **cambtek.com**



DISTRIBUTED BY: